



# USER MANUAL

## Air Conditioner Unit

- Installation should only be carried out by qualified technicians.
- For your convenience, please read this manual carefully and carry out all instructions in full.
- Please keep this manual in good condition for your reference.



## DE-COMMISSIONING, DISMANTLING & DISPOSAL

This product contains refrigerant under pressure, rotating parts, and electrical connections which may be a danger & cause injury  
All work must only be carried out by competent persons using suitable protective clothing and safety precautions.



Read the Manual



Risk of Electric Shock

**RoHS**






Unit is Remotely controlled  
& may start without warning



1. Isolate all sources of electrical supply to the unit including any control system supplies switched by the unit. Ensure that all points of electrical and gas isolation are secured in the OFF position. The supply cables and gas pipe work may then be disconnected and removed. For points of connection refer to unit installation instructions.
2. Remove all refrigerant from each system of the unit into a suitable container using a refrigerant reclaim or recovery unit. This refrigerant may then be reused, if appropriate, or returned to the manufacturer for disposal. Under NO circumstances should refrigerant be vented to atmosphere. Where appropriate, drain the refrigerant oil from each system into a suitable container and dispose of according to local laws and regulations governing disposal of oily wastes.
3. Packaged units can generally be removed in one piece after disconnection as above. Any fixing down bolts should be removed and then unit lifted from position using the points provided and equipment of adequate lifting capacity. Reference MUST be made to the unit installation instructions for unit weight and correct methods of lifting. Note that any residual or spilt refrigerant oil should be mopped up and disposed of as described above.
4. After removal from position the unit parts may be disposed of according to local laws and regulations.
5. Meaning of crossed Out wheeled dustbin: Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well being. When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposals at least free of charge.

In case one of the following conditions happens, please check the unit as shown below. If the problems persist, please contact the dealer or the customer service center.

Fault	Check
The unit does not operate	<ul style="list-style-type: none"> <li>● Has the Earth Leakage device tripped?</li> <li>● Has the circuit breaker or fuse tripped</li> <li>● Fuse tripped</li> <li>● Is the electrical Voltage normal( between 90&amp;110%)</li> </ul>
The cooling or heating performance is poor	<ul style="list-style-type: none"> <li>● Is the air filter dirty (if the filter has been installed)?</li> <li>● Are the air inlet and outlet blocked?</li> <li>● Are the door and window closed?</li> </ul> <p>When the unit has been running for 15 minutes, measure the temperature of the air inlet and outlet. If the two temperature differ 8°C or above during cooling and differ 14°C or above during heating, it is normal.</p> 
The indoor fan does not appear to operate	<ul style="list-style-type: none"> <li>● During heating or under certain other circumstances the indoor fan may slow down or stop as part of the systems normal operation.</li> </ul>
Indoor Unit produces water vapour	<ul style="list-style-type: none"> <li>● This can occur when the cold air from the unit meets the warm air in the room .This can occur when the cold air from the unit meets the warm air in the room.</li> </ul> 
The indoor unit makes strange sounds	<ul style="list-style-type: none"> <li>● When the air conditioner stops, or changes between cooling and heating modes a gurgling or whooshing sound is normally made</li> <li>● The indoor unit will expand or contract due to the temperature change and may produce creaking or groaning sounds</li> <li>● A gurgling sound is made by the flow of refrigerant through the pipes</li> </ul> 
The air conditioner seems to produce unpleasant	<ul style="list-style-type: none"> <li>● The air conditioner cannot produce smells by itself but odours or bacteria taken in from the room may accumulate inside the unit and produce unpleasant odours.</li> <li>● Try cleaning the air filter. If the problem persists the unit must be cleaned by a professional so please contact your dealer or service center.</li> </ul>
During heating the indoor fan only operates after the unit starts heating and the operation light on the wired controller (optional) flashes.	<ul style="list-style-type: none"> <li>● In order to prevent cold drafts in the room the indoor fan only runs when the air is hot during heating mode. When there is a requirement for heating and the unit starts to heat then the fan will start, after a short time.</li> <li>● The unit has a memory function, in case of a power failure, will restart after power is restored in the same mode and with the same setting as before the power failure.</li> </ul>



## Contents

Safety Precaution.....	2
Components name.....	6
Notices of installation.....	7
Installation of indoor unit-----Duct Type.....	10
Installation of indoor unit----- Ceiling cassette split air conditioner unit.....	12
Installation of indoor unit----- Ceiling &Floor Air Conditioner Unit.....	15
Installation of outdoor unit.....	16
Installation of tubing.....	18
Electrical connections.....	21
Wiring of indoor unit and outdoor unit.....	23
Commissioning.....	26
Operation instructions.....	27
Fault code - variable speed.....	28
Fault code - constant speed.....	30
Maintenance and service.....	31



## Safety precautions

In order to prevent the risk of death, serious injury or damage to property please comply with the following important safety instructions.

The extent of possible harm is described by the following symbols.

 <b>Warning</b>	This symbol indicates danger of death or serious injury.
 <b>Caution</b>	This symbol indicates danger of death or damage to property.

The unit must be operated in accordance with the following symbols.

	This symbol indicates something which is strictly forbidden.
	This symbol indicates something which must be adhered to.

It is important that the unit is correctly commissioned after the installation is complete to ensure it is operating correctly.

After commissioning you should use this manual to explain to the user the correct method of operating the unit and its maintenance requirements.


### Protective measure

#### Warning

- Your air conditioner is not designed to be installed by yourself and should only be installed by a qualified, competent and trained technician.
  - The presence of Mains Voltage electricity and high pressure refrigerant gas make installing this system a specialist task which you should not attempt yourself.
  - Any electrical work on the air conditioner should only be carried out by a qualified, competent and trained technician and not by yourself.
- Ensure the electrical power is disconnected during service and maintenance.



#### Warning

- This unit must be correctly earthed. 
  - Incorrect grounding will cause earth leakage and electric shock.
  - Earth Leakage Protection must be installed.
- Failure to do so carries the risk of electric shock and fire.



#### Caution

- Do not install either the indoor or outdoor unit in a place where flammable or explosive gases are present or there is a high risk of a fire or explosion occurring.
- Ensure the unit drain pipe work is properly connected and made or water leaks will occur.



#### Important

- This unit is not suitable for operation by minors or disabled users.
- Children should be prevented from operating the air conditioner.

## Maintenance and service

### • At the beginning of each season you should check

1. There are no physical obstructions at the air inlet or outlet of either indoor or outdoor unit. These will prevent the unit from operating correctly and cause seriously damage to your unit.
2. The electrical cables are in good condition, particular the earth cable. Damage must be immediately rectified by a trained person.
3. Are the drains blocked? If the drain is blocked then the unit will be prevented from operating and a seriously water leak may occur.

### • Check at the end of service season

Operate for 2-3 hours under the ventilation condition; remove the moisture of the indoor unit.



Close power after the unit stops.

Note: When the unit is not in use for a long time, please cut-off power supply.

If the unit is stopped by the remote controller, it will still consume some power.

### • Other check

1. After several seasons you should have the dealer or service center clean the indoor and outdoor unit thoroughly. This will ensure the unit continues to work correctly.
2. It is possible that contaminant build up inside the unit may cause drain blockage, bad smells, water leaks and shortage of airflow, cooling or heating performance. If these occur you should have the dealer or service center clean the system and investigate.
3. Do not attempt to clean the inside of either the indoor or outdoor unit yourself. This is a hazard to health and may cause system failure.



### Fault diagnosis

#### Caution

- If you experience abnormal operation such as the smell of burning, water leaks, loud noises etc. turn off the power supply and contact the dealer or service center. If you leave the unit running then major damage may occur.
- Do not attempt to service or repair the unit yourself. Errors by untrained personnel can cause short circuits, gas leakage and fire as well as being a serious danger to health and safety. Please have all service work done by your dealer or a trained service center.

**When there is the following phenomenon, please contact the dealer or the customer service center.**

- Unusual Sound During Operation
- Water Leakage at the indoor unit
- The unit won't respond to the controller
- Burning smells or smoke
- Failure of the electrical circuit or tripping the fuse
- Cables are abnormally hot


















- Stop the unit and cut off power supply

## Fault code - Constant speed

When the air conditioner fails, the controller board's timing receiver, the outdoor unit PCB board's trouble light and the wired controller's LCD panel will show the corresponding fault code according to the different fault indication. Specific response is as follows:

Error code	Display type	Error code definition	Recovery or not	Problem possible reasons
E0	Blink 11 times, stop 2 seconds	Lack of refrigerant	No	Compressor internal protection
				System less refrigerant
				Reversing failure of 4 way valve
E1	Blink 1 times, stop 2 seconds	TA (Indoor temperature sensor) is abnormal	Yes	Sensor damage
				Poor contact of sensor
E2	Blink 2 times, stop 2 seconds	TW (Defrosting temperature sensor) is abnormal	Yes	Sensor damage
				Poor contact of sensor
E3	Blink 3 times, stop 2 seconds	TE (Indoor coil sensor) is abnormal	Yes	Sensor damage
				Poor contact of sensor
E4	Blink 4 times, stop 2 seconds	Drainage system failure	Yes	Damage of water pump
				Damage of float switch
				Float switch is locked
E5	Blink 5 times, stop 2 seconds	Communication failure	Yes	Communication line sequence error
				Bad contact of communication line
E6	Blink 6 times, stop 2 seconds	Outdoor protection (phase sequence)	No	The power line is short of phase
				Power line phase sequence error
E7	Blink 7 times, stop 2 seconds	TL (Outdoor condensing temperature sensor) is abnormal	Yes	Sensor damage
				Poor contact of sensor
E8	Blink 8 times, stop 2 seconds	TP (Discharge temperature sensor) is abnormal	Yes	Sensor damage
				Poor contact of sensor
E9	Blink 9 times, stop 2 seconds	Low pressure protection	Yes	System less refrigerant
EA	Blink 10 times, stop 2 seconds	Outdoor protection (Discharge temperature is too high.)	No	External protection device action
F1	Blink 5 times, stop 2 seconds	Communication failure between indoor unit and outdoor unit	Yes	Communication line sequence error Bad contact of communication line
F2	Blink 2 times, stop 2 seconds	Exhaust overtemperature protection	Yes	System plugging or fault of the outdoor fan
F3	Blink 3 times, stop 2 seconds	Outdoor fan 1# is abnormal	Yes	Bad connection of fan connection
				Motor damage
F4	Blink 4 times, stop 2 seconds	Indoor fan is abnormal	Yes	Bad connection of fan connection
				Motor damage
F5	Blink 5 times, stop 2 seconds	Outdoor temperature sensor	Yes	Sensor damage
				Poor contact of sensor
F6	Blink 6 times, stop 2 seconds	Compressor overcurrent protection	No	Compressor plugging
				Low voltage
F7	Blink 7 times, stop 2 seconds	Dial switch is abnormal	Yes	Dial switch is wrong
F8	Blink 8 times, stop 2 seconds	Indoor power protection	Yes	Wiring error
F9	Blink 9 times, stop 2 seconds	High pressure protection	Yes	The clogging of the condenser
				Abnormal operation of the outdoor fan
				System plugging

**Note:** When the wired controller or control board consecutive two minutes had not received the right signals, then the unit is turned off and instructed corresponding fault code. Once the communication restore, the unit automatically resume.

Don't use flammable sprays near the air conditioner.		IF there are some abnormalities (such as the smell of scorching), please shut down and cut off power supply.	
Don't use open flame near the air conditioner.		Don't use sub-standard or damaged wires.	
Don't attempt to repair the air conditioner yourself.		Don't put fingers or other objects into the air conditioner. Don't touch metal parts of the heat exchanger.	
Your air conditioner is designed for comfort cooling or heating. It is not designed for any other purpose and specifically should not be used for storing food, animals, plants, precision instruments, art or antiques, nor any other special item. It is not designed for specialist computer rooms.		Do not use naked flames where the air flow from the unit can reach directly. The air from the unit will interrupt the combustion process and either extinguish the flame or misdirect it. Either is a danger of fire or explosion.	
Your air conditioner contains water and may also drip if the humidity of the room is too high. Do not, therefore, place any object under the unit which could be damaged in the event of water dripping on it.		Do not direct the air from the unit directly onto animals or plants as this may be harmful to them.	
Do not sit in the cold air stream directly for long periods.		Ensure the room properly ventilated.	
Check the air conditioner regularly to ensure correct operation and that nothing has become loose.		Do not clean the air-conditioner with water.	
		Before cleaning the air conditioner, cut off the power.	 

**Warning**

- Do not attempt to install this unit yourself. Incorrect installation can cause refrigerant or water leakage, electric shock, fire or other to health and safety or property.
- Where the unit is installed must be solid enough to withstand the weight of the unit. If it is not then there is the danger of the structure collapsing or the unit falling creating a danger of serious injury or death.
- The installation should be mindful of potential damage by strong winds, earthquakes or other natural phenomena. These should not be able to cause the unit to fall over and cause an accident.
- The electrical installation should be in accordance with local and national specifications and only be carried out by qualified personnel in accordance with installation instructions. The air conditioner should have its own dedicated power supply.
- Ensure the power supply is of sufficient capacity for the unit , or there is a risk of fire, electric shock or other failure.
- The wiring should be made correctly using the specified cable and properly secured to avoid the risk of external forces causing the connections to come loose. Failure to do this runs the risks of electric shock or fire.
- Ensure the refrigerant pipe work is fully evacuated and leak tested and do not over charge with refrigerant. Over charging with refrigerant can cause a leak to occur after installation.
- Leaks can cause a high concentration of refrigerant in an area which may result in sudden death by asphyxiation.
- Do not carry out any electrical work unless the power supply has been disconnected. If the unit is installed in a small room there is danger of a leak causing the refrigerant gas concentration to exceed the maximum permissible for safe breathing and this can cause sudden death by asphyxiation. Please consult your dealer about preventative measures such as audible visual leak detectors.
- When making pipe connections be sure to use a torque wrench and tighten the flare nuts to the correct torque. Over and under tightened nuts can cause refrigerant gas to leak. Do not operate the compressor unit the pipe work has been correctly made, leak tested and evacuated.
- While performing installation or maintenance ensure that no foreign objects can enter the either the unit or pipe work.
- If the supply cord damaged , it must be replaced by the manufacturer , its service agent or similarly qualified persons in order to avoid a hazard.

**Caution**

- Ensure the drain pipe is installed in accordance with the installation instructions and adequately insulated to protect against condensation forming. Badly installed drain pipe work can cause expensive damage due to water leaks.
- Your air conditioner contains sophisticated electronic controls which may be subject to interference from radios, televisions, mobile telephones or other electronic goods. Do not operate these items near to the air conditioner or they may cause the unit to fail. We suggest maintaining a distance from these items to indoor unit at least 1 meter and to the outdoor unit of at least 2 meter. Depending upon the type and frequency of the electromagnetic signal you may need to leave a longer distance than this.

Error code	Display type	Error code definition	Recovery or not	Problem possible reasons
H4	Blink 4 times, stop 8 seconds	Low pressure switch "LPS" failure	Yes	System pressure lower than low pressure switch limit.
				Low pressure switch failure
				Instantaneous power-off
				Stop valve closed
				In cooling mode indoor unit EXV close or block
				In heating mode outdoor unit EXV close or block
E1	Blink 1 time, stop 8 seconds	4 way valve protection	Yes	In heating mode outdoor unit fan stop
				In heating mode outdoor unit air outlet block
E3	Blink 3 times, stop 8 seconds	DC inverter discharge temperature "Td" too high shutdown protection	No	4 way valve block
				Outdoor unit PCB failure
				System less refrigerant
				DC inverter Compressor failure
				Compressor air return filter block
				EXV open degree is small or EXV block
				Gas pipe stop valve closed
E8	Blink 8 times, stop 8 seconds	Coil Center temperature sensor "Tcm" too high shutdown protection	Yes	Liquid pipe stop valve closed
				System exhaust sensor failure
				Outdoor unit PCB failure
				System over refrigerant
J2	Blink 2 times, stop 8 seconds	The communication between outdoor unit and indoor unit failure	Yes	EXV open degree is small or EXV block
				System exhaust sensor failure
J3	Blink 3 times, stop 8 seconds	The communication between PCB and INV module failure	Yes	Outdoor unit PCB failure
				The communication wire between indoor unit and outdoor unit disconnect, short circuit or connect incorrect.
				Indoor unit main power failed or PCB failure
3H/5H	Blink 11 times, stop 8 seconds	The communication between main PCB and DC fan motor drive module failure	Yes	The connection between driving module and main PCB failure
				The communication part of outdoor unit control PCB failure
J7	Blink 7 times, stop 8 seconds	Outdoor unit main control PCB ERROM module failure	No	Frequency driving board failure
				Compressor failure
31	Blink 1 time, stop 8 seconds	Module protection (F0)	Yes	DC fan operation failure
				Mail PCB failure
32	Blink 2 times, stop 8 seconds	Module hardware protection	Yes	Supply voltage below level let the current excessive
				Supply voltage exceed limit
33	Blink 3 times, stop 8 seconds	Module software protection	Yes	Outdoor fan stop or low speed
				Supply voltage below level let the current excessive
34	Blink 4 times, stop 8 seconds	Compressor unconnected	Yes	Supply voltage exceed limit
				Outdoor fan stop or low speed
35	Blink 5 times, stop 8 seconds	Compressor phase current overload protection	Yes	Supply voltage below level let the current excessive
				Supply voltage exceed limit
36	Blink 6 times, stop 8 seconds	DC bus voltage over-voltage or under-voltage failure	Yes	Outdoor fan stop or low speed
				Supply voltage below level
37	Blink 7 times, stop 8 seconds	Temperature sensor of drive module heat fins failure	Yes	Supply voltage exceed limit
				Driving module failure
38	Blink 8 times, stop 8 seconds	Drive module high temperature limit frequency failure	Yes	Inverter driving board failure
				Driving module failure
39	Blink 9 times, stop 8 seconds	Drive module high temperature shutdown protection	Yes	Compressor failure
				Compressor failure
3E	Blink 14 times, stop 8 seconds	DC inverter compressor running out of step	No	Once confirm the unrecoverable

## Fault code - Variable speed

After indoor and outdoor units shut down due to failure, failure code will display on wired controller or remote receiving board. In case of normal protection, no failure code will display on wired controller or remote receiving board of indoor unit. Among others, wired controller doesn't automatically send warning, which requires pressing CHECK button to display corresponding failure codes. Remote receiving board directly displays failure codes. After failures are removed, display will automatically disappear.

### Indoor unit error code explanation

Error code	Display type	Error code definition	Recovery or not	Problem possible reasons
A1	Blink 1 time, stop 8 seconds	Indoor ambient temperature sensor failure	Yes	Indoor PCB is broken The fuse of indoor PCB is broken temperature sensor broken , or exceed test limit
A2	Blink 2 times, stop 8 seconds	Temperature sensor about middle position of evaporator failure	Yes	Indoor PCB is broken The fuse of indoor PCB is broken temperature sensor broken , or exceed test limit
A5	Blink 5 times, stop 8 seconds	Indoor water pump failure	Yes	Water pump no power Water pump switch short-circuit or unconnected Water pump is broken Drain pipe block or up lean Indoor PCB is broken
A6	Blink 6 times, stop 8 seconds	Indoor DC fan failure or broken	Yes	DC fan motor drive module failure DC fan failure
A8	Blink 8 times, stop 8 seconds	Indoor unit ERRPROM module failure	No	Indoor unit PCB is broken Error module is broken.
A9	Blink 9 times, stop 8 seconds	The communication between indoor unit and outdoor unit failed	No	The communication wire between indoor unit and outdoor unit is broken. Indoor unit power close OR PCB is broken
AA	Blink 10 times, stop 8 seconds	The communication between indoor unit and wire controller failed	No	The communication wire between indoor unit and outdoor unit is broken. Indoor unit power close OR PCB is broken Wire controller is broken


### Outdoor unit error code explanation

Error code	Display type	Error code definition	Recovery or not	Problem possible reasons
C1	Blink 1 time, stop 8 seconds	Ambient temperature sensor "Tao" failure	Yes	Temperature sensor failure or test temperature exceed limit Sensor connection is incorrect Outdoor unit PCB failure
C2	Blink 2 times, stop 8 seconds	Defrosting temperature sensor "Tdef" failure	Yes	Temperature sensor failure or test temperature exceed limit Sensor connection is incorrect Outdoor unit PCB failure
C3	Blink 3 times, stop 8 seconds	Discharge temperature of inverter compressor "Td" failure	Yes	Temperature sensor failure or test temperature exceed limit Sensor connection is incorrect Outdoor unit PCB failure
C6	Blink 6 times, stop 8 seconds	Suction pipe temperature of compressor "Ts" failure	Yes	Temperature sensor failure or test temperature exceed limit Sensor connection is incorrect Outdoor unit PCB failure
C8	Blink 8 times, stop 8 seconds	Coil Center temperature sensor "Tcm" failure	Yes	Temperature sensor failure or test temperature exceed limit Sensor connection is incorrect Outdoor unit PCB failure
FH	Blink 11 times, stop 8 seconds	Low discharge temp protection	Yes	Temperature sensor failure Outdoor unit PCB failure Lack of refrigerant
H1	Blink 1 time, stop 8 seconds	DC inverter compressor high pressure switch "HPS" failure	No	System pressure exceed high pressure switch limit High pressure switch failure Instantaneous power-off Stop valve closed Outdoor unit fan stop or air outlet block In heating mode indoor unit fan stop or EXV block

## ⊘ Forbidden

- Do not try and install, service or remove the air conditioner yourself. Contact the dealer or service center.
- Do not mount this system in a vehicle, ship, aircraft or other place which will move while the unit is in operation.
- Do not install this unit where there will flammable or explosive gases present. If these leak and accumulate near the air conditioner then a fire or explosion may result.

## ⚠ Warning

- Do not use any refrigerant other than the one indicated on the outdoor unit nameplate. Do not allow foreign bodies or moisture to enter the pipe work during installation and ensure the pipe work is fully leak tested and evacuated before running the unit. If the refrigerant gas becomes contaminated with moisture, air or other gases then unit will not perform correctly and there is a risk of leakage, explosion or other damage to the unit.
- Do not extend the power cable or use multiple power cables.
- Do not place the outdoor unit near balconies or anywhere children can climb onto it and potentially fall off and injure themselves.
- The indoor unit should be mounted at least 2.5 meters above the ground to prevent people from interfering with it. If there is a refrigerant leak during installation immediately ventilate the space thoroughly.
- Once the installation is complete carry out a thorough leak test of the system.
- Never allow refrigerant gas to make contact with sparks or naked flames and burning refrigerant releases poisonous gases.
- Ensure the electrical supply cable is properly protected and connections are made properly. Bad connections will cause the cable to overheat and potentially cause electric shocks or fire. An Earth leakage protector must be installed. The entire electrical installation should be checked by a qualified electrician to avoid the potential for electrical shocks or fire.
- The unit must be adequately earthed. 
- Never connect the earth wire to gas or water pipes, lighting rods or telephone cables. Inadequate grounding of the earth cable may lead to the danger of serious injury or death by electric shock.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. (Only for the AC with CE-MARKING)
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. (Except for the AC with CE-MARKING)

## WEEE Warning

Meaning of crossed out wheeled dustbin:

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact your local government for information regarding the collection systems available.

If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.


When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposals at least free of charge.




**Component name**

**Indoor Unit:**


**Ceiling cassette split air conditioner unit**






**Duct Type**



**Ceiling & Floor Air Conditioner Unit**







**Outdoor Unit:**




**Operation instructions**

Following the instructions below will allow you to get the best from your air conditioner

Proper use method	
<ul style="list-style-type: none"> <li>● <b>During cooling, avoid direct sunshine</b> Please close the curtains.</li> </ul> 	<ul style="list-style-type: none"> <li>● <b>Do not obstruct air flow</b> Do not place objects near the air inlet or outlet of either the indoor or outdoor unit. If the air flow is obstructed then the air conditioner will be unable to perform correctly.</li> </ul>
<ul style="list-style-type: none"> <li>● <b>Try not to cool excessively</b> Suggestion of setting temperature. cooling: 26-28°C Dehumidify: 20-24°C</li> </ul> 	<ul style="list-style-type: none"> <li>● <b>Do not use other heating equipment when unit run cooling function</b> Using heating equipment will affect the cooling effect.</li> </ul> 
<ul style="list-style-type: none"> <li>● <b>Keep the windows or doors shut</b> Open windows or doors will increase the amount of heating or cooling the amount of heating or cooling required and may prevent the unit being able to preform correctly.</li> </ul> 	<ul style="list-style-type: none"> <li>● <b>Clean the air filter regularly</b> Dirty filters will prevent the unit from being able to perform correctly and may cause expensive damage. Clean regularly by washing or with a vacuum cleaner. Replace if necessary. We recommend filter cleaning once a month or more frequently if required.</li> </ul>

**⚠ Caution**


- Before cleaning the air filter stop the unit on the controller and turn off at the power supply.
- Do not clean the air conditioner with water or you risk both electric shock and short circuit.
- When cleaning the air filter ensure you pay attention to health and safety.



**Cleaning the air filter**

In order to ensure the best performance from your air conditioner clean the air filter regularly. We recommend cleaning once a month or more frequently if required.

1. The filter can be cleaned using a vacuum cleaner or with soap and water.
2. Take off the air filter
  - ① First, take off the bolt casing on the air inlet grille, then take off the bolts using the screwdriver, and take off the filter net.
  - ② Set the filter net back to the air inlet grille, fix its bolt and the casing.



**⚠ Caution**

- Electricity, Dangerous! Cut off all the power supply before maintenance.
- When the filter is very dirty it can be washed in detergent and hot water (below 40°C).
- Ensure the filter is fully dry before reinstallation to avoid risk of electric shock or short circuiting
- Do not dry the filter using direct sunlight.



## Connection method

### To connect the indoor unit

Open the cover of terminal box cover. Connect the cables according to the electric connection diagram. And check all cables are connected safely, securely and correctly.


### To connect the outdoor

Open the outdoor unit electrical access panel and connect cables according to the circuit diagram on the backside of the access panel. And check all cables are connected safely, securely and correctly. Earth wire must be connected at the right location.

Note: The PC board of outdoor unit whose power supply has phase sequence protection. Please pay attentions to it while connecting power cable.

After all connections have been made and checked, the pipe work has been leak tested and charged and the drain pipe work tested then the pipes and cables should be bound together as follows.

1. Locate the drain pipe at the bottom along with the control cable.
2. Place the insulated refrigerant pipes on top.
3. Place the mains cable on top of these.
4. Bind carefully with tape.
5. Ensure the drain pipe is not damaged.



**Caution: Do not squash the drain pipe during binding operation!**

## Commissioning

### Items should be checked before Commissioning

1. Does the line match the circuit diagram?
2. When installing multiple machines at the same time, please confirm that the connection lines of the indoor and outdoor units should not be mistakenly connected.
3. Is the unit correctly grounded?
4. Is the screw loose in the wire connection ?
5. Is the insulation value more than 10MΩ ?
6. Is the pipe size correct ?
7. Is the pipe insulated material properly laid? Are the gas pipes and liquid pipes heat insulation ?
8. Are liquid side and air side cut-off valves fully open ?
9. Are the refrigerant additive charge and refrigerant pipe length recorded ?

### The steps of Commissioning



1. Turn on the Power Supply and select cooling operation as shown in the remote controller section of this manual.
2. After the 3minute compressor protection delay. Check the indoor unit louver is operating correctly and both the indoor and outdoor units are operating correctly without abnormal noise. Check that cold air is produced after a short time.
3. Select heating operation on the controller and wait for 5 minutes. Check that the indoor fan starts correctly and that hot air is produced after a short time.
4. Select Fan operation on the controller. Check that the fan operates correctly in all fan speeds.
5. Test the other functions on your controller as shown in the controller section of this manual.
6. Select Cooling operation, and check the drain pump operates correctly.
7. After confirming the unit operates correctly, turn the unit off and disconnect the power supply.

## Notices of installation

### Correct installation

#### Caution:

- When unpacking, open the carton, please remove the packing foam first, then take out the air conditioner.
- Do not touch the heat exchanger at the rear of the indoor unit with your hands or any other object!
- Handling with the handle and side angle , please handle with care , Do not drop the unit or allow it to fall during transport.
- When the outdoor unit is to be lifted, please use two slings longer than 8m and insert cushioning material between the slings and outdoor unit to avoid damaging the casing.




Preparation for installation accessories	Installation tools
<p>Before installation the following items are not included with the unit but will be required for the installation and should be obtained locally.</p> <ol style="list-style-type: none"> <li>1. Four M12 suspension bolts</li> <li>2. PVC drain pipe</li> <li>3. Connection pipe</li> <li>4. Heat insulation materials(PE, thickness is over 8mm) used for connecting pipe</li> <li>5. Five large binding tapes and five small binding tapes</li> <li>6. Outdoor power cable, and indoor and outdoor power connecting cable</li> </ol>	<p>Besides the common tools, during connecting the pipe the following tools are required:</p> <ol style="list-style-type: none"> <li>1. Torque spanner(42 N•m, 65 N•m, 100 N•m)</li> <li>2. Pipe cutter (cut copper pipe)</li> <li>3. Refrigerant cylinder (when the pipe is lengthened, the refrigerant must be added)</li> <li>4. Nitrogen cylinder ( to prevent oxidation and to clean pipe when weld pipe)</li> <li>5. Pressure gauge</li> <li>6. LPG</li> <li>7. Pipe clamp</li> <li>8. Welding torch</li> </ol>

## Installation drawing

This installation chart is for reference only. Power cable for indoor and outdoor unit must comply with national standards.

Power supply: single-phase 220-240V,50Hz/60Hz;  
three-phase 380-415V,3N~,50Hz/60Hz.





Recommended Specification of Circuit breaker :


Model	Circuit Breaker	
	1 phase	3 phase
AOU-53AHPDC1A	16A	/
AOU-71AHPDC1A	20A	/
AOU-105AHPDC1A	25A	/
AOU-140AHPDC3A	40A	25A
AOU-180AHPDC3A	40A	25A

## Constant speed-Cooling Only


### • 5.0KW




### • 7.0KW



### • 10.5KW




### • 14KW/16KW





## Variable speed

### • AOU-53AHPDC1A-AOU-105AHPDC1A (Single-phase)



### • AOU-140AHPDC3A-AOU-180AHPDC3A (Three-phase)



### Attention to Installation site of indoor unit

#### For convenience of maintenance, please reserve a service port.

Ensure the following conditions are satisfied and confirm the position with the customer.

1. The position must allow the air to not be obstructed.
2. The distance away from the wall and obstacles is shown in the below drawing.
3. The installation site should be convenient for water draining (See "Installation of drainage pipe" for details).

#### Warning

4. For ducted type indoor unit, the suspension site should be able to support the weight 4 times more than the indoor unit. There should be no increase in noise and vibration. If it needs to be reinforced, the installation should be carried out after reinforcement (if reinforcement is poor, the indoor unit will fall and cause damage).

5. The indoor unit must be away from sources of heat or steam and way from entrances.

6. The indoor unit position is near the power source (special line).

7. The indoor unit position must allow for easy connection to the outdoor unit.

8. The indoor unit position should keep away from direct sunlight and moisture.

9. The height inside the ceiling should reach the drainage requirements to ensure the installation of indoor unit.


10. The unit cannot be installed in the washhouse (it will cause electric shock).

11. In the inlet and outlet of indoor unit, protective barriers should be installed to prevent finger from inserting or contacting the fan with high speed and metal fin.

### Matter requiring attention


#### Must carry out a full inspection to the following place before installation

1. In restaurants, kitchens and other eating places, dust, flour, grease steam and other cooking by products will easily attach to the indoor fan, heat exchanger and drain pump. This will cause the performance to reduce and cause the unit to spray water, leak and may lead to the drain pump or other components to fail. Please consider adopting the following improvement measures.





The capacity of the kitchen extract fan and extract hood should be great enough to ensure that the oil, steam, flour and other cooking products will be exhausted through it and not attracted into the air conditioner. The indoor unit should be far enough away from the cooking and food preparation equipment to ensure that cooking products are not attracted into the unit.






2. When installing the unit in a factory, ensure it is situated in a place where it will not be contaminated by oil, powder, iron fillings or dust.
3. Do not install near potential sources of combustible gas.
4. Do not install where acidic or corrosive gases are present.



#### • 14KW/16KW(Single-phase)




#### • 10.5KW/14KW/16KW(Three-phase)



## Installation of indoor unit-----Duct Type

### The location of hoisting bolt




Packing Size (cm)	A mm	B mm	C mm	D mm	E mm	F mm	G mm	H mm
107*80*36	652	890	927	510	75	700	202	290
143*80*36	967	1250	1287	510	75	700	185	290
143*80*39	967	1250	1287	510	75	700	214	320
158*88*45	1117	1400	1437	585	75	775	273	380
123*83*30	812	1000	1039	600	52	700	177	246
163*83*30	1212	1400	1439	600	52	700	177	246
100.5*58*27.5	532	700	750	412	23	460	110	200
130.5*58*27.5	832	1000	1050	412	23	460	110	200

### The suspension drawing of indoor unit


#### Warning

- Must seriously fasten bolts and nuts. The loosening would lead to air conditioner falling and so on.
- As shown, the indoor unit should be leaning to the drain hole to be convenient for drainage.



### Installation of duct

There are two installation methods of duct ,as follow.






- Use canvas to connect the indoor unit and duct in order to reduce unnecessary vibration.

## Wiring of indoor unit and outdoor unit





1. Some of indoor and outdoor unit have L\N grounding terminals, which can be supplied separately by indoor and outdoor units power, Recommending outdoor unit power supply
2. The schematic diagram in the instruction manual is for reference only, it is specific to the object on the units.

### Constant speed-Heat pump type



#### • 3.5KW-5.0KW(Single-phase)



#### • 7.0KW-8.7KW(Single-phase)



#### • 10.5KW(Single-phase)



## Selection of electrical parts

- The Interconnection cord connect the indoor and outdoor units. You must first choose the right cable size before preparing it for connection.
- Minimum Cross-Sectional Area of Power Cable and interconnection cord.

### North America

Appliance Amps (A)	AWG
10	18
13	16
18	14
25	12
30	10
40	8

### Other Regions


Rated Current of Appliance (A)	Nominal Cross-Sectional Area (mm <sup>2</sup> )
> 3 and ≤ 6	0.75
> 6 and ≤ 10	1
> 10 and ≤ 16	1.5
> 16 and ≤ 25	2.5
> 25 and ≤ 32	4
> 32 and ≤ 40	6

- The size of the interconnection cord, power cable, fuse, and switch needed is determined by the maximum current of the unit. The maximum current is indicated on the nameplate located on the side panel of the unit. Refer to this nameplate to choose the right cable, fuse, or switch.
- Note: Core number of cable refer to the detailed wiring diagram adhered on the unit which you purchased.

## Installation of drainage pipe


1. The drainage pipes should have good insulation measures. The specific steps are as follows:

- The drainage hoses should be tightly clamped with the inner water outlet and the drainage pipe respectively, then fix with a hoop, as shown in Fig ①.
- Wrap the heat insulation cotton on the drain insulation pipe and the hoop, as shown in Fig ②.
- Tighten the sponge with a bandage, as shown in Fig ③.




2. The drain pipe must have a downward gradient (1/50~1/100).

If the drain pipe is installed ups and downs or upward, it will lead to water back flow or leakage etc.




- During pipe connection, do not use too much force to the drain joint of indoor unit.
- The joint is PT1.
- There is a drain hole on each side of indoor unit; unused drain pipe must be closed.

Note: The drain pipe must be wrapped heat insulation material, otherwise it will cause condensation or water drops.  
Heat insulation material: rubber insulation pipe with thickness more than 8mm.



## Installation of indoor unit----- Ceiling cassette split air conditioner unit

### Select installation site



### The dimension of indoor unit

Ceiling cassette split air conditioner unit have two kinds of shapes, Fig A and Fig B. Please choose the size according to the shape.




Fig A





Fig B



Packing Size (cm)	E mm	F mm
65.5*65.5*29.5	260	315
91.5*91.5*32	250	305
91.5*91.5*36	290	345

## Electrical connections

### Warning

- All electrical works must be carried out & checked by a qualified electrician and must adhere to the IET regulations, local and national legislation and industry best practice. The system must have its own independent power supply. An all pole isolating disconnect switch with at least 3mm contact separation must be installed. The power cord and connecting cable should be either as supplied with the unit or otherwise as specified in this manual.
- Do not attempt any electrical works yourself.
- An Earth Leakage Protector, Power Switch and Circuit Breaker or Fuse must be installed in the dedicated power supply or there is the risk of electric shock.
- The fuse specification of single-phase control panel is T5AL 250V; The fuse specification of three-phase control panel is T3.15AL 250V.
- The grounding must be reliable. If grounding is not correct, it may lead to electric shock.
- All power cables should be properly secured with cable ties so that external forces cannot disconnect the wires from the terminals. Improper connections or insecure fastening can cause electric shocks or fire.


### Caution

- Do not connect the earth cable to gas or water pipes, telephone lines, lightning rods or the earth cables of other products.
- Once the indoor and outdoor unit have been switched on, do not cut off power off power supply in 1 minute, (the system automatically set) otherwise abnormal operation will be caused.


### Caution

1. The definition of power cord is the power supply cable from the isolating switch attached to the dedicated power supply to the indoor unit or outdoor unit. Interconnecting cable for the indoor and outdoor unit is the power cable that connects indoor unit and outdoor unit.
2. Above-mentioned definitions are the specifications of power supply, power cord and interconnecting cable of indoor unit and outdoor unit of all different types of air conditioners.
3. To avoid voltage drops, when the cross sectional area of a power cable core reaches the minimum size, and the power cord is lengthened, you should choose another bigger power cable size.
4. The power cord connected to the indoor unit is 227 IEC53 type cable. The power cord connected to outdoor unit and the interconnecting cable between indoor unit and outdoor unit are both H05RN-F (neoprene) stranded wire. If you use single-strand two ply wire, please select wire with larger cross-section area by one size and a special electric jacket should be used.

When the installation position of indoor unit is higher than that of the outdoor unit.



When the installation position of indoor unit is lower than that of the outdoor unit.




#### ●Connection of tubing and indoor unit

Remove the copper nut from indoor unit and insert it over the unflared tube before making the flare, align the flaring side of the connecting pipe with the connector of indoor unit, lightly coat the flare and nut with refrigerant oil, screw the copper nut onto the connector of indoor unit and tighten it (tightening torque is shown in the table above).

#### ●Connection of tubing and outdoor unit

Follow the instructions for flaring the indoor unit as Fig:



### Evacuating or purging the pipe work

Before releasing the refrigerant in the outdoor unit into the pipe work and indoor unit it is necessary to ensure that there are no foreign objects, water or non-condensing gas in the refrigeration system. For that purpose, it is necessary to evacuate or purge the system:

#### Evacuation

When evacuating, ensure that all the connecting pipes between indoor unit and outdoor unit have been tightened.

1. Unscrew the nut of the service port from the low pressure valve of the outdoor unit, and connect a service hose connected to a composite pressure gauge to this service port.
2. Connect the vacuum pump to the composite pressure gauge via another service hose, turn on the pressure gauge and vacuum pump to evacuate the indoor unit and pipes, so that after vacuuming, the absolute pressure is not greater than 50Pa.
3. Switch off the valve of the composite pressure gauge, stop the vacuum pump and ensure the pressure does not increase after 20 minutes.

#### Gas Purging

During purging, the connection between outdoor high pressure valve and liquid pipe should be loosened.

1. Unscrew the nut of the service port from the low pressure valve of outdoor unit, and connect it with a service hose that has a schraeder depressor. The other end of the rubber hose is connected to the refrigerant tank.
2. Open the valve of the refrigerant tank, so that the refrigerant will flush the connecting pipe of indoor unit and outdoor unit at high speed, in order to discharge the air in the pipe. You can feel that refrigerant flows out at the outlet of connecting liquid pipe.
3. When you feel that refrigerant flowing out is getting cold, tighten the outdoor high pressure valve and connecting pipe of the liquid pipe and maintain the state for more than 10s.
4. Close the valve of the refrigerant tank, and by using soap and water, check for leaks at all of the connections.
5. After confirming that there is no leak, remove the service hose.


After evacuating or Gas Purging operation is completed, re-install the service valve nut on the low pressure valve of the outdoor unit, unscrew the spindles of high-pressure valve and low-pressure valve of the outdoor unit, and this will supply refrigerant to the pipe work and indoor unit.

Important: Depending upon the legislation in your country Gas Purging may be illegal and therefore you should follow the Evacuation Process if you are in any doubt. In particular this is the case in the European union.

### Adjust the refrigerant quantity

When pipe length exceeds 5m, please add refrigerant according to the table below:

Refrigerant pipe	Refrigerant pipe specification		Additional fill of refrigerant(kg/m)
	Gas pipe(mm)	Liquid pipe(mm)	
Tubing between indoor unit and outdoor unit	φ9.52×0.75	φ6.35×0.75	0.02
	φ12.7×1	φ6.35×0.75	0.02
	φ15.88×1	φ9.52×0.75	0.04
	φ19.05×1	φ9.52×0.75	0.04



Note:

1. This table is for reference only.
2. The joints shall not be reused, unless after re-flaring the pipe.
3. After installation, check the stop valve cover whether be fixed effectively.

### Suspension foundation of the indoor unit

#### 1. Select the suspension foundation



The suspension foundation is a structure of either wooden frame or reinforced concrete. It must be firm and reliable to bear the weight of more than 200kg and capable of bearing vibration for long periods.

#### 2. Fixing of suspension foundation

Fix the suspension bolts as shown on the right either by a steel or by wooden bracket.

If this unit is installed on a sloping ceiling, a cushion block should be installed between the ceiling and the air outlet panel, in order to ensure that the unit is installed on a level surface.


This is as shown in the drawing as follow.



### Suspension of the indoor unit


The indoor unit should be suspended as shown in the sketch below:

1. Adjust the relative position of the suspension hook on the suspension bolt.
2. Tighten the bolt and ensure that four hooks are in close contact with the nuts and washers, and the unit is suspended firmly and reliably onto the hooks.
3. Ensure it is secure and does not shake or sway after the unit is installed.
4. Ensure that the center of the indoor unit is in alignment with that of the opening in the ceiling.



### Installation of drainage pipe


1. The drain pipe should be properly insulated to prevent the generation of condensation. It should be installed with a downward gradient (1/100-150).



### Caution

In order to ensure the drainage water come out successfully, the unit must be horizontal or declined to drain hose when finished installation.

2. The unit has a drain pump which will lift up to 1200mm. However after the pump stops, the water still in the pipe will drain back and may overflow the drain tray causing a protective stop. For this reason please install the drain pipe as shown on the right.



3. When draining multiple units into a common drain line, this common drain should be installed about 100mm below each unit drain outlet, as shown in the drawing on the right.




## Grille Installation

Please refer to the picture on the right.


The grille has four clips which attach to corresponding hangers on the unit and the grille should be positioned using these first. The grille is then fixed into the position by four bolts which are accessed through the four corner panels on the grille. The four connection bolts are located inside the inlet panel of the grille.

Note: During installation please ensure that the air vane motor in the grille corresponds to the position of the refrigerant pipe entry into the indoor unit.



## Removing the air filter

1. Ensure the unit is switched off and the power is off.
2. Each unit has two retention clips on the grille. These must be pressed and then pushed to the open position.
3. The filter access panel may now be lowered allowing you to remove the filter from its four retaining clips.
4. Ensure the filter is fully clean and dry before replacing.
5. Ensure the retention clips on the grille are fastened position after replacing the filter.



## Connection of refrigerant pipe

The standard refrigerant pipe length is 5m long. If the distance between the indoor and outdoor is longer is longer than this, then the pipe needs to be extended.

Please refer to the following table for the limitations of each unit as far as maximum distance and height.

Do not exceed these limits or compressor failure may result.

Keep the pipe separation length and the number of bends to the lowest possibility and always follow the shortest path for the pipe installation.

As the pipe length and number of bends increases the performance of the unit decreases and energy use increases.

Specification Model	Connecting pipe dim. (φmm)		Max. Connecting pipe & length			Max. Fall (m)	Max. Bending number
	liquid pipe	Gas pipe	liquid pipe	Gas pipe	Max. Length(m)		
AOU-53AHPDC1A	6.35	12.7	7.94	15.88	20	15	4
AOU-71AHPDC1A	9.52	15.88	9.52	19.05	20	15	4
AOU-105AHPDC1A	9.52	15.88	9.52	19.05	30	20	6
AOU-140AHPDC3A	9.52	19.05	12.7	22.2	50	30	8
AOU-180AHPDC3A	9.52	19.05	12.7	22.2	50	30	8

● Only refrigeration quality, deoxidized, seamless, phosphor copper tube suitable for R410a should be used as a refrigerant pipe.

● Requirements for connecting pipe between indoor unit and outdoor unit:

1. Machining dimension of flared pipe section is as shown in following table;
2. When flaring nut is connected, some refrigerant oil should be applied on the flared pipe section (both inside wall and outside wall), and screw the nut by 3-4 thread pitches before finally tightening it;
3. Tightening torque is shown in the following table;
4. Carry out leakage test after the completion of the installation.

Tubing specification (mm)	Tightening torque (N•m)	Machining dimension of flared pipe section(mm)	Shape of flared mouth	Apply refrigerant oil
φ6.35	15-19	8.3-8.7		
φ9.52	35-40	12.0-12.4		
φ12.7	50-60	15.4-15.8		
φ15.88	62-76	18.6-19.0		
φ19.05	98-120	22.9-23.3		

● Precautions to prevent compressor oil return defect

1. Horizontal pipes should incline toward the outdoor unit using a 20:1 slope.
2. If there is a height difference between the indoor and outdoor unit, oil traps should be installed in the interconnecting gas (large) pipe:
  - When the vertical pipe height difference is less than 5 meters, an oil trap should be installed at the bottom of the gas (large) pipe.
  - When the vertical pipe height difference is more than 5 meters, then for every 5 meters an oil trap must be installed at the bottom of the gas (large) pipe, and a short loop (liquid ring) should be installed at the exit of the indoor unit liquid (small) pipe:
  - When the connecting gas pipe vertical height difference is less than 5 meters but the constant rise distance is too long, an oil trap should be installed in the gas (large) pipe every 10 meters.
3. When the outdoor and indoor units are at the same elevation, the oil deposit bend and liquid ring do not need to be installed, if the horizontal connecting pipe length is less than 10 meters. When the horizontal connecting pipe length is more than 10 meters, install an oil trap in the gas (large) pipe every 10 meters.

Note: This chart is for explanation purposes. An actual installation maybe different from this and it should consider the site conditions. When making an oil trap the radius of the bend should be between 1.5 and 2 times the pipe diameter.



## Installation of tubing

### Installation instructions


- Ensure the following when long pipe work is required and this is to be brazed.
  - Please fully install the tubing and any brazing work before connecting the pipes to the unit.
  - Oxygen Free Nitrogen must be used inside the pipes to prevent oxidation.
- If there are many joints requiring brazing during the installation of long tubing, please use an in line filter. All tubes must use refrigeration quality dehydrated copper pipe and not normal plumbing copper and should be free from moisture, dust or other contaminants.
- Please purge the pipe with nitrogen or to eliminate any dust inside before oxidation.
- Please install the pipeline according to the pipe direction, and don't repeatedly bend and then straighten a piece of pipe more than 3 times (this will damage the copper). Please use a pipe bender to bend the pipe. After preparing a length of pipe slide pipe insulation material over it.
- After the connecting pipe work has been completed, connect to the indoor unit using the flare connector provided. Disconnect the flare nut from the indoor unit valve and place over the pipe facing the indoor unit. Flare the pipe as shown in this manual, and after coating both the flare nut and both inside and outside of the flare with a light coat of refrigerant oil, tighten the nut using a torque wrench to tighten the nut and a spanner to hold the valve on the unit. Always use a torque wrench set to the correct torque and always hold the indoor unit valve steady with another spanner. Do not under or over tighten. This process is carried out for both the small and large pipes.
- Connect to the outdoor unit in a similar manner.
- After the connection of tubing is completed, please carry out a full leak test on the pipe work and ensure the pipe work and connections do not leak and everything is fully insulated.

### Heat insulation and sealing



Copper tube and drain pipe must be separately insulated to prevent condensation or water leakage.

- The copper tube should be properly insulated using materials designed for insulating air conditioner pipe and heat resistive above 120°C.




- Matters requiring attention in areas with very high humidity level:
 

The air conditioner has been fully tested in various humidity conditions. However, if it runs for long periods of time in a high humidity environment so water drops will arise. The following heat insulation material should be carried out.


  - The indoor unit should be externally insulated using 10-20mm thickness glass fibre.
  - The normal pipe insulation is around 8mm for tubing.

- Sealing the wall:

To prevent rainwater or other foreign bodies from entering the room and air conditioner after installing the tubing and drain pipe, the gap between wall hole and tubing, drain pipe and electric wire should be sealed with mastic, sealant rubber or putty, or poor performance or leakage will result. If the outdoor unit is higher than indoor unit, tubing should be bent to prevent rainwater entering the room or air conditioner along the piping system.



- The connection of air outlet needs insulating.




- The pipes of air outlet are connected under insulating.


## Installation of indoor unit----- Ceiling & Floor Air Conditioner Unit

### Select installation site


- Ceiling installation



- Wall-Mounted installation



### The dimension of indoor unit



Packing Size (cm)	A mm	B mm
101*72.5*29	930	841
136*72.5*29	1280	1192
171*72.5*29	1630	1543

### Ceiling installation


- Select the suspension foundation
 

The suspension foundation is a structure of either wooden frame or reinforced concrete. It must be firm and reliable to bear the weight of more than 200kg and capable of bearing vibration for long periods.
- Fixing of suspension foundation
 

Fix the suspension foundation bolts either as shown on the right or by a steel or wooden bracket.
- The suspension of indoor unit
 

the indoor unit should be suspension as shown below:

  - Adjust the relative positions of the suspension hooks.
  - Tighten the nuts and ensure that the hooks are tightly connected to the nuts and shims.
  - After the unit is installed ensure it is secure and does not shake or sway.




- In order to ensure the drainage water come out successfully, the unit must be declined to the bottom side of unit when finished installation.
- Please make sure the front side higher, otherwise it may cause drainage come out from the air outlet.

- Installation of drainage pipe

- The drain pipe should be properly insulated to prevent the generation of condensation.
- Pipes it should be installed with a downward gradient (1/100~150) to allow the water to drain away.
- The pipe should not rise at any point.





### Wall-Mounted installation



The unit must be horizontal or declined to drain hose when finished installation.


## Installation of outdoor unit

### Outdoor unit Dimensions



Outdoor Unit Size of Shape W1(W2)*H*D (mm)	A mm	B mm
730(780)×545×285	540	280
785(845)×550×295	485	280
800(860)×545×315	545	315
825(880)×655×310	540	335
900(950)×700×350	630	350
970(1045)×803×395	675	410
940(1010)×1320×370	625	364
940(1008)×1366×401	610	388

### Select installation site



- Where you site the outdoor unit will have a direct affect upon its performance. In order for the outdoor unit to operate at its best you should carefully follow these instructions. In particular "short cycling" (allowing discharge air to return to the rear of the unit) should be avoided as this will significantly reduce the cooling and heating performance.
  - The discharge air which is expelled from the front of the unit should not be allowed to short cycle and return back to the unit.
  - Ensure there is ample space around the unit for service and maintenance.
  - Ensure the unit is installed on the level. Do not allow a slope of more than 5°.
- The following figures show the right installation and wrong installation:

Wrong installation			
Right installation			

### Caution


- The installation place must be well-ventilated, so that the unit can be move enough air to operate correctly.
- The installation place must be enough firm to support the weight of outdoor unit and can isolate noise and vibration.
- Avoid direct sunlight, and if necessary a sun shelter should be mounted.
- The installation place should allow for the drainage or rainwater and water produced during defrosting.
- The installation place should prevent the unit from getting buried in a snow drift.
- The unit should not be installed so that the fan blows into strong winds.
- Ensure that neither the air from the outdoor unit nor noise produced by it will affect the neighbours.
- The unit must not be in a position where people will pile rubbish onto it or where it will be affected by exhaust gases.
- After the unit is installed, it is necessary to use a plastic belt to twine the drain pipe and the connecting pipe together to prevent damage caused by the pipeline in contact with sharp objects.

### Warning

If the outdoor unit runs in a atmospheric environment where there are oil sources (including machine oil), salts (marine areas), and sulphide gas (near hot springs or oil refineries), these substances may cause unit faults.

### Installation

- Install a drainage channel to allow the condensate to flow smoothly away.
- During installation please ensure that the foundations are secure and level to avoid vibration and noise.
- Please bolt the outdoor unit down securely.
- The bolts for connecting the outdoor unit should protrude 20mm above the surface of the base.
- Do not just use the four corners as a foundation to support the unit.



### Caution

Please install a drainage channel around the foundations to drain away condensate when the outdoor unit is installed on a roof please ensure that it is solid enough to bear the weight of the outdoor unit, that the installation will not affect its water tightness and condensate is able to drain away freely.